
RECOMMENDED TOOLS

















MODEL NO.:F01 101

DESCRIPTION: SINGLE HANDLE LAVATORY FAUCET




Parts list




NO.	PART NAME
1	Handle
2	Screw
3	Index
4	Trim cap
5	Cartridge lock nut
6	Cartridge
7	Body
8	Aerator
9	Copper tube
10	Screw
11	Base
12	O-ring
13	Rubber washer
14	Clamp
15	Screw
16	Lock nut
17	Aerator wrench
18	Allen key
19	Flexible hose

Faucet installation



- 1. Put the faucet into the installation hole of the basin. Make sure o-ring be on the base of faucet. Assemble screw #15 to the base of faucet, and assemble rubber washer #13 and clamp #14 to screw #15. Then assemble lock nut #16 by basin wrench to screw #15 to fix the faucet.
- 2. Assemble the 2 flexible hose to the faucet with adjustable wrench.
- 3. Connect the flexible hose to water supply valve (not included), and tighten it with adjustable wrench. DON'T OVER TIGHTEN! Caution: make sure connect the hot and cold supply lines to supply valves correctly. Warning: The supply valves are not included, please purchase them in plumbshop.

Checking and testing



- 1.Remove the aerator by aerator wrench. Turn the faucet handle all the way on, turn on hot and cold water supply and flush water lines for one minute. Reinstall aerator by aerator wrench.
- 2. Check all connections at arrows for leaks, re-tighten it if necessary. BUT DON'T OVERTIGHTEN